

Graphic Application Instructions

Tools Required:



Trimming Blade



Felt Tipped Squeegee



Spray Bottle (2)



Clean Lint Free Cloth



1/2" Wide Masking Tape

Note:

- Wash hands prior to installation.
- Vehicle and decal temperature should be between 70 and 90 degrees Fahrenheit.
- Leave vehicle in warm facility for 5 hours after application.
- DO NOT wash car for 5 days after installation.
- DO NOT apply in direct sunlight.
- Apply in a dust-free environment.
- Use a generous amount of solution.

Alcohol / Water Solution:

In a spray atomizer:

- (1) Isopropyl Alcohol Bottle
- (1) Water Bottle

Application Instructions:

- Thoroughly clean surface, remove all old adhesive, dirt, lint, oils, etc.
- Clean surface with rubbing alcohol using a lint-free cloth.
- Before removing the backing, hold the graphics up to the desired area to get a general idea of how the graphics will look. Using masking tape to hold in place is suggested.
- Wrap a soft lint-free cloth around your squeegee.
- Remove half of the backing paper, spray a light mist of water to the adhesive side of the graphic.
- Lightly set the graphic onto surface, making sure that it is properly aligned. Start from the center of the graphic and squeegee the water outward.
- Remove remaining backing paper and repeat the last two steps.
- Let graphic application dry for approximately 24 hrs before riding.